



## EO EXPLODING DRAWING

NO.	PARTS NAMES	NO.	PARTS NAMES
1	BODY	31	ROTOR
2	BODY DECORATION COVER	32	SPRING
3	BODY COVER	33	BAIL ARM SUPPORT PIN
4	SCREW	34	KICK LEVER
5	BUSHER	35	BAIL ARM
6	OSCILLATION GEAR	36	SCREW
7	SCREW	37	BAIL ARM COVER
8	SLIDE	38	SCREW
9	SLIDE GUIDE PIN	39	SCREW
10	SCREW	40	WASHER
11	BALL BEARING	41	LINE ROLLER
12	DRIVE GEAR	42	BALL BEARING
13	BALL BEARING	43	BAIL ASS'Y
14	BODY SIDE	44	BAIL HOLDER
15	BODY SIDE DECORATION COVER	45	SCREW
16	SCREW	46	WASHER
17	ANTI-REVERSE BUTTON	47	ROTOR NUT
18	SCREW	48	CLICK GEAR
19	ANTI-REVERSE	49	WASHER
20	SPRING	50	SPOOL ASS'Y
21	SPRING	51	LINE WASHER
22	BALL BEARING	52	DRAG WASHER
23	PINION GEAR	53	LINE WASHER
24	ONE WAY CLUTCH	54	DRAG WASHER
25	BUSHER	55	LINE WASHER
26	BALL BEARING	56	DRAG WASHER
27	ONE WAY CLUTCH BUSHER	57	DRAG KNOB
28	MAIN SHAFT	58	WASHER
29	ONE WAY CLUTCH FIXED PLATED	59	HANDLE CAP
30	SCREW	60	HANDLE ASS'Y